

# **Data Sheet | Flyscreen Door**

# **Transit v363**

## **DESCRIPTION**

Semi-assembled pleated flyscreen door for installation inside sliding side door openings of Ford Transit v363 (2014-present) campervans.



#### **OPERATION**

Manual step-less adjustment. Closing from right to left (as seen from the inside) for left-hand steered vehicles, optionally from right to left for right-hand steered vehicles.

# STANDARD DIMENSIONS (MM)

Top guider profile length	1,183
Bottom guider profile length	1,295
Overall height	1,671

Disclaimer | The specifications in this data sheet are for information purposes only and may be subject to change without prior notice. © Horrex 2024

# **MATERIAL SPECIFICATIONS**

# Top guider profile

Extruded aluminium 23.5 x 24.6 mm (WxH) in dark grey (± RAL7021) powder coated (conditions apply)

# **Pull bar**

Extruded aluminium 50 x 17 mm (WxH) in dark grey (± RAL7021) powder coating (conditions apply)

# **Bottom guiding profile**

Extruded anodized aluminium 35.5 x 21.5 mm (WxH)

# Side panel (optional)

Black ABS panel, straight for customisation or pre-shaped, aligned with the bodywork and/or interior of the van, for effective protection against insects (conditions apply)

# Corner pieces and caps

Colour coordinated injection moulded parts in PA6 and PA6.6

#### Insect screen mesh

Single pleat black polyester mesh 1.3 x 1.3 mm (mesh opening), optional FR in accordance with standard FMVSS/CMVSS 302 (conditions apply)

# **INSTALLATION**

On-face fixation on the inside with 4 clips underneath the door rubber at the top and 4 screws at the bottom. The required mounting space between door rubber and top cabinet is 27 mm and between sliding door and kitchen cabinet is 20 mm

## **CLEANING**

A soft damp cloth with mild detergent

### **PACKAGING**

Individually or bulk with mounting set

# **SPECIAL NOTE**

Combine a flyscreen door with genuine UCS combi-blinds for a total insect screen solution









