



Remove the top profile



De-tension both cord tensioners with an Allen key and remove them out of the profile.



Disassemble the cassette- and pull bar profiles and disassemble the mesh.



Place the new mesh pack and slide it in the “cassette profile” with the side where the tape is glued.



Cut the mesh pack to the correct size



Slide the pull bar profile on the mesh and assemble the plastic guiding pieces. The 3 cords on the top side of the mesh pack get out of the pull bar on the bottom side. The 3 cords at the bottom side of the mesh pack get out of the pull bar on the top side.



Mount the cord tensioner with a knot.



Slide the 2 cord tensioners on the "closing profile" and mount the plastic piece in the "closing profile".



Mount the top guiding profile





Tension the cords with the cord tensioner and an Allen key.